



[illegible][illegible]

SEE IGNITION DRAWING
FOR CORRECT IGNITION
MODULE & COIL WIRING

SEE IGNITION DRAWING
FOR CORRECT IGNITION
DIST INPUT WIRING

MICROTECH MT-8
SEQUENTIAL

```

VAC/BOOST NIPPLE
FROM MANIFOLD

BATTERY +
GND
FUEL PUMP RELAY
FUEL
S VOLT
T.P.S.
AIR TEMP SENSOR
AIR TEMP SENSOR
INJECTOR DRIVE #1
INJECTOR DRIVE #2
INJECTOR DRIVE #3
INJECTOR DRIVE #4
IGNITION ON +12V
IGN OUTPUT #1 (C)
IGN OUTPUT #2 (C)
IGN OUTPUT #3
IGN OUTPUT #4
CRANK INPUT #1 (C)
CRANK INPUT #2 (C)
EXC OUTPUT #1
EXC OUTPUT #2

```

Title		MT-8		VER 2.0		Revision		2.0	
Size		Number		FUEL DRAWING		Sheet		1 of 2	
A3						Date:		26-01-1998	
						File:		H18 FUEL/2	
						Drawn By:		DOH	
						7		8	